

# Ethernet

## Application Specific Function Block Manual

Version 14.1.1 Rev 1

## NOTE

Progress is an on-going commitment at G & L Motion Control Inc. We continually strive to offer the most advanced products in the industry; therefore, information in this document is subject to change without notice. The illustrations and specifications are not binding in detail. G & L Motion Control Inc. shall not be liable for any technical or editorial omissions occurring in this document, nor for any consequential or incidental damages resulting from the use of this document.

DO NOT ATTEMPT to use any G & L Motion Control Inc. product until the use of such product is completely understood. It is the responsibility of the user to make certain proper operation practices are understood. G & L Motion Control Inc. products should be used only by qualified personnel and for the express purpose for which said products were designed.

Should information not covered in this document be required, contact the Customer Service Department, G & L Motion Control Inc., 672 South Military Road, P.O. Box 1960, Fond du Lac, WI 54936-1960. G & L Motion Control Inc. can be reached by telephone at (920) 921-7100 or (800) 558-4408 in the United States or by e-mail at [glmotion.support@danahermotion.com](mailto:glmotion.support@danahermotion.com).

**DISCLAIMER:** All programs in this release (application demos, application specific function blocks (ASFB's), etc.) are provided "AS IS, WHERE IS", WITHOUT ANY WARRANTIES, EXPRESS OR IMPLIED. There may be technical or editorial omissions in the programs and their specifications. These programs are provided solely for user application development and user assumes all responsibility for their use. Programs and their content are subject to change without notice.

Release 1705

Part Number M.1302.7711, Rev 1 (Catalog Number 1300.7521)

© 2000-2005 G & L Motion Control Inc.

IBM is a registered trademark of International Business Machines Corporation.

Windows 95, 98, NT, Microsoft, and MS-DOS are registered trademarks of Microsoft Corporation.

Pentium and PentiumPro are trademarks of Intel Corporation.

ARCNET is a registered trademark of Datapoint.

PiC900, PiCPro, MMC, PiCServoPro, PiCTune, PiCProfile, LDO Merge, PiCMicroTerm and PiC Programming Pendant are trademarks of G & L Motion Control Inc..

# Table of Contents:

## Ethernet ASFB Manual

---

<b>CHAPTER 1-Application Specific Function Block Guidelines .....</b>	<b>1-1</b>
<b>Installation.....</b>	1-1
<b>Revisions .....</b>	1-1
Network 1 .....	1-1
Network 2 .....	1-1
Network 3 .....	1-2
<b>ASFB Input/Output Descriptions.....</b>	1-2
Network 4 .....	1-2
<b>Using ASFBs.....</b>	1-2
<b>CHAPTER 2-Ethernet ASFBs.....</b>	<b>2-1</b>
E_MAIL.....	2-3
E_TCPRD.....	2-5
E_TFTPSV.....	2-6
E_TFTPCL.....	2-8
E_UDPCL1.....	2-10
E_UDPSV1.....	2-12
<b>-Index.....</b>	<b>Index-1</b>

## NOTES

# CHAPTER 1 **Application Specific Function Block Guidelines**

## **Installation**

---

The following guidelines are recommended ways of working with Application Specific Function Blocks (i.e. ASFBs) from G&L Motion Control.

The Applications CD includes the ASFB package as follows:

- .LIB file(s) containing the ASFB(s)
- source .LDO(s) from which the ASFB(s) was made
- example LDO(s) with the ASFB(s) incorporated into the ladder which you can then use to begin programming from or merge with an existing application ladder

When you install the Applications CD, the ASFB paths default to:

C:\Program Files\G&L Motion Control\Applications vxx.x.r\ASFB

and

C:\Program Files\G&L Motion Control\Applications vxx.x.r\Examples

*where vxx.x is the PiCPro for Windows version number that these ASFBs and examples were built under. The .r is the revision number of the Application software itself.*

The .LIB files and source .LDO files are put in the ASFB subdirectory. The example .LDO files are put in the Examples subdirectory.

## **Revisions**

---

The first four networks of each ASFB source ladder provide the following information:

### **Network 1**

The first network just informs you that the ASFB is provided to assist your application development.

### **Network 2**

The second network is used to keep a revision history of the ASFB. Revisions can be made by G&L Motion Control personnel or by you.

The network identifies the ASFB, lists the requirements for using this ASFB, the name of the library the ASFB is stored in, and the revision history.

The revision history includes the date, ASFB version (see below), the version of PiCPro used while making the ASFB, and comments about what the revision involved.

When an ASFB is revised, the number of the first input (EN\_\_ or RQ\_\_) to the function block is changed in the software declarations table. The range of numbers available for G&L Motion Control personnel is 00 to 49. The range of numbers available for you is 50 to 99. See chart below.

<b>Revision</b>	<b>G&amp;L Motion Control revisions</b>	<b>User revisions</b>
1st	EN00	EN50
2nd	EN01	EN51
.	.	.
.	.	.
.	.	.
50th	EN49	EN99

### **Network 3**

The third network describes what you should do if you want to make a revision to the ASFB.

## **ASFB Input/Output Descriptions**

---

### **Network 4**

The fourth network describes the ASFB and defines all the inputs and outputs to the function block.

## **Using ASFBs**

---

When you are ready to use the ASFB in your application, there are several approaches you can take as shown below.

- Create a new application LDO starting with the example LDO for the ASFB package. The advantage is that the software declarations table for the ASFB has been entered for you.
- If you already have an application LDO, copy and paste the example LDO into yours. The software declaration tables for both LDOs will also merge.

## CHAPTER 2 **Ethernet ASFBs**

These are the Ethernet application specific function blocks (ASFBs). These ASFBs provide drop-in functionality for Ethernet support. They are easy to use function blocks that enable the PiC or MMC to communicate and share data with other devices over an Ethernet connection. They provide support for:

### 1. **PiC to PiC (or MMC) data exchange**

E\_UDPCL, E\_UDPSVR, E\_TCPCL, and E\_TCPSVR are obsolete. These functions had logic problems that caused them to lock. They should be replaced with E\_UPDCL1 and E\_UDPSV1. When you replace the ASFB's you will have to make the following changes to your ladders:.

1. You will have to add three variables to the top of your data structures as follows:

<b>BUFR</b>	<b>STRUCT</b>	data to write to UPD client/Space for data read from client
.SeqNumb	USINT	Sequence Number
.RW_CMD	USINT	0 = Write, 1 = Read
.Size	INT	Total number of bytes in the message, including the header and data
.Data	xxx	Data elements can be any data type and up to 508 bytes
	END_STRUCT	

These three variables are used by the new protocol and need to be in the structure. Note the CNT input was rename to SIZE. It is the size of the BUFR structure, it includes the header and data variables.

2. Replace the E\_UDPSVR with E\_UDPSV1. The E\_UDPSV1 ASFB has an additional BOOL input called READ, thus if you have logic below the old one you need to add a row before replacing it with the new one. Read = on, Write = off.

3. Replace the E\_UDPCL with E\_UDPCL1. The E\_UDPCL1 ASFB has an additional UDINT output called RCNT which is the total number of retries.

### 2. **File transfers**

TFTP (trivial file transfer protocol) is used over UDP to transfer individual RAM-DISK files over Ethernet.

### 3. **Internet E-mail sending capability**

The PiC or MMC can send a user-programmable text message to a user-specified E-mail address via SMTP (simple mail transfer protocol). The PiC or MMC does not have the capability to receive or respond to E-mail with this ASFB.

These function blocks implement several of the procedures described in the PiCPro Function/Function Block Reference Guide "Overview of Using Ethernet-TCP/IP Function Blocks", located after the IPWRITE function block description.

**Note:** The OPC Server (OLE for Process Control) capability over Ethernet is not part of this package. It is available separately. The OPC Server provides a tool for the exchange of data between a PC and a PiC or MMC using the widely accepted standard, OPC. That package consists of an ASFB for the PiC or MMC and the PC-resident OPC Server software.

The files for this Ethernet ASFB package are listed on the following page.

**Note:** Every .LDO on the CD has a corresponding .REM file. The .REM file contains all the network comments found in the .LDO file. If you move a .LDO file to a different location, be sure to move its .REM file to the same directory.

### **Ethernet ASFBs**

---

E_INET.LIB	Library for the internet E-mail ASFB
E_MAIL.LDO	Source file for the E-mail (SMTP) client
E_PICXCG.LIB	Library for the data exchange ASFBs
E_TCPRD.LDO	Source file for the TCP data read
E_TFTP.LIB	Library for the TFTP ASFBs
E_TFTPCL.LDO	Source file for the TFTP client
E_TFTPSV.LDO	Source file for the TFTP server
E_UDPCL1.LDO	Source file for the UDP client
E_UDPSV1.LDO	Source file for the UDP server
E_UDP1.LIB	Library for the UDP ASFBs

Also included with the Ethernet ASFB package are example ladders for the use of the respective ASFBs as follows:

E_CLIENT.LDO	Example of the client ASFBs
E_SERVER.LDO	Example of the server ASFBs



---

---


## E\_MAIL

SMTP E-mail Client

USER/E\_INET

---

---



**Inputs:** RQ00 (BOOL) - requests message (one shot)  
SLOT (USINT) - slot number of the Ethernet module  
NAMZ (STRING) - IP address of post office on LAN, zero-terminated  
TO (STRING) - E-mail address of recipient  
FROM (STRING) - sending PiC name (optional)  
SUBJ (STRING) - subject header  
BODY (STRING) - body of the message

**Outputs:** DONE (BOOL) - execution without error  
FAIL (BOOL) - an error has occurred  
ERR (INT) - error number from IP functions that occurred during execution

```
<<INSTANCE NAME>>:E_MAIL(RQ00 := <<BOOL>>, SLOT := <<USINT>>,
  NAMZ := <<INT>>, TO := <<USINT>>, FROM := <<USINT>>, SUBJ :=
  <<USINT>>, BODY := <<USINT>>, DONE => <<BOOL>>, FAIL =>
  <<BOOL>>, ERR => <<INT>>);
```

This function block enables a PiC or MMC to send a text-based e-mail message via SMTP using the Ethernet module. This function block does not allow the PiC or MMC to receive or respond to e-mail.

E\_MAIL allows a PiC or MMC to send the text-based message entered at the BODY input to the SMTP address specified at the TO input. Up to 256 bytes of text may be sent as the BODY of the message, with additional bytes for the TO, FROM, and SUBJ inputs.

In order to use this function block, you must have an SMTP server installed on your network. The address of the SMTP Server (or the "Post Office") must be specified at NAMZ. SMTP server software may be obtained on the World Wide Web. This function block was tested using Seattle Labs SLMail 2.7 for Windows 95, available from <http://www1.seattlelab.com>.

The FROM input is used only to specify the origin of the message. It is not for the purpose of replying to the PiC or MMC.

The DONE output indicates that the outgoing message has been successfully transferred to the SMTP server. It does not indicate successful reception of the message by its intended recipient.

The FAIL output is energized in the case of an incomplete transfer of the message to the SMTP server. If it is not energized, however, it does not necessarily indicate successful reception of the message by the intended recipient.

The ERR output specifies the type of error. Error codes are listed after E\_UDPSVR in Table 2-1 Ethernet ASFB Error Codes. The ERR value of -1 could be caused by an incorrect NAMZ value or an incorrect SMTP Server configuration. The ERR value of -2 could be caused by an incorrect NAMZ value or the SMTP Server is offline.

---

---


## E\_TCPRD

Read TCP Data

USER/E\_PICXCG

---

---



```
<<INSTANCE NAME>>:E_TCPRD(EN00 := <<BOOL>>, HNDL :=  
  <<UINT>>, BUFR := <<BYTE>>, CNT := <<UINT>>, OFST := <<UINT>>,  
  ACTV => <<BOOL>>, DONE => <<BOOL>>, FAIL => <<BOOL>>, ERR =>  
  <<INT>>, CURR => <<UINT>>);
```

This function block is used to read data from a TCP connection via the Ethernet module.


Since TCP is based on data streaming, not all of the data to be read may be available at any one time. The function block provides a convenient method of reading the stream data until the requested number of bytes are read.

When the EN00 input is energized, the function block will read data from a TCP socket defined by the HNDL input. After a successful read, if the actual number of bytes read is less than the requested number of bytes to read, the function will initiate another read. While the read(s) is active the ACTV output will be energized. When all the requested data has been read the DONE output will energize and the ACTV output will de-energize.

The EN00 input must remain energized until a DONE or FAIL is reported after which the EN00 input can be de-energized. To initiate another byte count read request the EN00 input must see a low to high transition.

The DONE output is set if the number of actual bytes read at the CURR output equals the number of requested bytes to read at the CNT input and indicates a successful read. The FAIL output is set if a read was unsuccessful.

The ERR output specifies the type of error and are listed in Table 2-1 Ethernet ASFB Error Codes.



**Inputs:** EN00 (BOOL) - enables execution (continuous)  
SLOT (USINT) - slot number of Ethernet module  
STAT (STRUCT) - status of current file transfer

**Outputs:** OK (BOOL) - execution without error  
FAIL (BOOL) - an error has occurred  
ERR (INT) - error number from IP functions that occurred during execution  
RERR (INT) - error number from RAMDISK functions that occurred during execution

```
<<INSTANCE NAME>>:E_TFTPSV(EN00 := <<BOOL>>, SLOT :=  
  <<USINT>>, STAT := <<STRUCT>>, OK => <<BOOL>>, FAIL =>  
  <<BOOL>>, ERR => <<INT>>, RERR => <<INT>>);
```

This function block allows a PiC or MMC to service TFTP file transfer requests for a file on the RAMDISK.

When enabled, the E\_TFTPSV function block allows a remote TFTP client to read and write files to and from the RAMDISK of a PiC or MMC in which the ASFB and Ethernet module are installed. The remote TFTP client could be either a PiC or MMC with the E\_TFTPCL function block or a PC with a TFTP client.

When the EN00 input is energized, the function block opens a UDP server socket on port 69 (this is the accepted TFTP port). Incoming TFTP requests are serviced one-at-a-time, with new requests being ignored if made before the completion of a previously requested transfer. If multiple simultaneous transfers are needed, the function block must be edited to accommodate this; the function block only serves one request at a time.

If a remote TFTP client attempts to write to a file that already exists on the RAMDISK of the PiC or MMC with the E\_TFTPSV function block, the existing file will be erased and replaced by the new file.

The STAT structure shows the status of the current file transfer. The structure format is as follows:

STAT STRUCT		Status of the current file transfer
.Active	BOOL	Indicates that a file transfer is active
.ReadWrite	BOOL	0 = file being read, 1 = file being writtten
.ClientIPAddr	STRING[25]	IP Address of the Client accessing the the file
.FileName	STRING[80}	Name of file being accessed
.Checksum	INT	Checksum, used to verify the size of the Struc- ture, set the Initial Value to 12345
	END_STRUCT	


#### IMPORTANT

The last data variable CheckSum must be included in the structure with the initial value set to 12345. This memory location with a known value is used by the ASFB to verify the size of the structure. If the structure is not the correct size, an error will be reported upon initialization.

The OK output is set if the function block is successful in opening and configuring a UDP socket and reset in the event of a failure.

The FAIL output is energized in the case of an IP or RAMDISK access error, with the specific error being designated at the ERR and RERR outputs, respectively.

The ERR output specifies the type of error. Error codes are listed after E\_UDPSVR in Table 2-1 Ethernet ASFB Error Codes. Error codes for the ERR and RERR output can be found in the PiCPro Online Help in Appendix B.



**Inputs:** RQ00 (BOOL) - requests transfer (one-shot)  
SLOT (USINT) - slot number of Ethernet module  
READ (BOOL) - read/write switch - read when enabled  
FILE (STRING) - filename in RAMDISK to read from/write to (Example: RAMDISK:\FILE.DAT)  
RFIL (STRING) - remote file to read/write (Example: if on a PC: C:\DATA.DAT, if on a PiC or MMC: RAMDISK:\FILE.DAT)  
NAMZ (STRING) - IP address of TFTP Server zero terminated

**Outputs:** DONE (BOOL) - execution complete without error  
FAIL (BOOL) - error, execution incomplete  
ERR (INT) - error number from IP functions that occurred during execution  
RERR (INT) - error number from RAMDISK functions that occurred during execution

```
<<INSTANCE NAME>>:E_TFTPCL(RQ00 := <<BOOL>>, SLOT :=  
<<USINT>>, CNT := <<UINT>>, READ := <<BOOL>>, FILE :=  
<<STRING>>, RFIL := <<STRING>>, NAMZ := <<STRING>>, DONE =>  
<<BOOL>>, FAIL => <<BOOL>>, ERR => <<INT>>, RERR => <<INT>>);
```

This function block allows a PiC or MMC to transfer files to and from a remote TFTP host. It allows a PiC or MMC to transfer files from its RAMDISK to a foreign host (another control (such as a PiC or MMC with E\_TFTPSV) or a PC) and from a foreign host to the RAMDISK of the PiC or MMC in which the ASFB and Ethernet module are installed.

When the RQ00 input is energized, this function block will initiate a TFTP read or write, depending on the status of the READ input. If the READ input is set, the client will get the file specified at the RFIL input and place that file in the RAMDISK file specified at FILE. If the READ input is not set, the client will copy the RAMDISK file specified at FILE input into the file specified at RFIL.

If the DONE output is energized, the client was successful in connecting to the server and transferring the data.

The FAIL output is energized in the case of an IP or RAMDISK error, with the specific error being designated at the ERR and RERR outputs, respectively.

The ERR output specifies the type of error. Error codes are listed after E\_UDPSVR in Table 2-1 Ethernet ASFB Error Codes. Error codes for the ERR and RERR output can be found in the PiCPro Online Help in Appendix B.

---

---


# E\_UDPCL1

UDP Client

USER/E\_UDP1

---

---



**Inputs:** EN00 (BOOL) - enables function (continuous)  
REQ (BOOL) - requests transfer (one-shot)  
SLOT (USINT) - slot number of Ethernet module  
NAMZ (STRING) - IP address or DNS name of UDP server, zero terminated  
PORT (UINT) - UDP protocol port number.  
READ (BOOL) - read/write switch - read when enabled  
SIZE (UINT) - number of bytes to be read or written  
BUFR (STRUCT) - data to exchange with UDP server  
CLSE (BOOL) - closes socket (one-shot)

**Outputs:** DONE (BOOL) - execution complete without error  
FAIL (BOOL) - error, execution incomplete  
ERR (INT) - error number from IP functions that occurred during execution  
CONN (BOOL) - socket open (connection is active)  
RCNT (UDINT) - number of retries

```
<<INSTANCE NAME>>:E_UDPCL(EN00 := <<BOOL>>, REQ := <<BOOL>>,
  SLOT := <<USINT>>, NAMZ := <<STRING>>, PORT := <<UINT>>, READ
  := <<BOOL>>, SIZE := <<UINT>>, BUFR := <<STRUCT>>, CLSE :=
  <<BOOL>>, DONE => <<BOOL>>, FAIL => <<BOOL>>, ERR => <<INT>>,
  CONN => <<BOOL>>, RCNT => <<UDINT>>);
```

This function block allows data to be read from or written to a PiC or MMC via the Ethernet module using UDP. For PiC to PiC, the other PiC or MMC will have the E\_UDPSV1 function block (the server for this client).

**Note: This ASFB replaces E\_UPDCL and E\_TCPL which are obsolete. See changes to BUFR input below.**

This function block implements the UDP Client connection described in the PiCPro Function/Function Block Reference Guide "Creating a UDP Client (Connectionless)", located after the IPWRITE function block description.

This function block acts only as a client. It will solicit information from server function blocks but will not service incoming requests from other controls or PCs.



The inputs at PORT, SIZE, READ, and BUFR must be the same in both the UDP client and the UDP server it is to communicate with.

Due to UDP packet size of 512 bytes, up to 508 bytes of data may be transferred per use of this function block. Four bytes are used for the client/server protocol header as shown below. As a result, SIZE must be less than or equal to 512.

The BUFR structure has the following format:

<b>BUFR</b>	<b>STRUCT</b>	
. SeqNumb	USINT	Sequence Number
. RW_CMD	USINT	0 = Write, 1 = Read
Size	INT	Size in bytes of BUFR Structure, including header data
.Data1	Any Type	Data elements can be made up of any data types up to and 508 bytes long
.Data2	Any Type	Data elements can be made up of any data types up to and 508 bytes long
...		
.DataX	Any Type	
END_STRUCT		

The SIZE input must be set to size in bytes of the BUFR structure, use the SIZEOF function to get the size of the BUFR structure.

When the REQ input is energized this function block will create a socket on the protocol port specified by PORT using the Ethernet board in the slot specified by SLOT. Once a socket is created, the function block will initiate a read or a write, depending on the status of the READ input. If the READ input is set, the client will get the data contained in the BUFR input of the server with which the client is communicating and place that data in the structure at BUFR on the client side. If the READ input is not set, the client will put the data from its BUFR input into the structure at BUFR on the server side.

If the DONE output is energized, the client was successful in connecting to the server and transferring the data.

The FAIL output is set if the function block was not successful in connecting to the server and transferring the data.

The ERR output specifies the type of error. Error codes are listed after E\_UDPSVR in Table 2-1 Ethernet ASFB Error Codes.

---

---


# E\_UDPSV1

UDP Server

USER/E\_UDP1

---

---



**Inputs:** EN00 (BOOL) - enables function (continuous)  
SLOT (USINT) - slot number of Ethernet module  
SIZE (UINT) - number of bytes to be read or written  
BUFR (STRUCT) - data to be read/space to be written to  
PORT (UINT) - UDP protocol port number. Choose any available UDP port above 1024.  
READ (BOOL) - off = write, on = read

**Outputs:** OK (BOOL) - execution without error  
FAIL (BOOL) - an error has occurred  
ERR (INT) - error number from IP functions that occurred during execution  
ACTV (BOOL) - currently reading or writing to input at BUFR

```
<<INSTANCE NAME>>:E_UDPSVR(EN00 := <<BOOL>>, SLOT :=  
  <<USINT>>, SIZE := <<UINT>>, BUFR := <<STRUCT>>, PORT :=  
  <<UINT>>, READ := <<BOOL>>, OK => <<BOOL>>, FAIL => <<BOOL>>,  
  ERR => <<INT>>, ACTV => <<BOOL>>);
```

This function block allows data to be read from or written to the PiC or MMC via UDP using the Ethernet module. For PiC to PiC, the other PiC or MMC will have the E\_UDPCL1 function block (the client for this server).

**Note: This ASFB replaces E\_UPDSVR and E\_TCPSVR which are obsolete. See changes to BUFR and additional Read input below.**

This function block implements the UDP Server connection described in the PiCPro Function/Function Block Reference Guide "Creating a UDP Server (Connectionless)", located after the IPWRITE function block description.

E\_UDPSVR allows an external UDP client (with E\_UDPCL) to read or write the number of bytes specified at the SIZE input from or to (respectively) the structure specified at BUFR, provided the client and the server have identical inputs at CNT, READ, and BUFR.

The BUFR structure has the following format:

```
BUFR      STRUCT  
. SeqNumb   USINT   Sequence Number  
. RW_CMD    USINT   0 = Write, 1 = Read  
Size        INT     Size in bytes of BUFR Structure, including header data  
.Data1      Any Type  Data elements can be made up of any data types up to and  
              508 bytes long  
.Data2      Any Type  Data elements can be made up of any data types up to and  
              508 bytes long  
...  
.DataX      Any Type  
END_STRUCT
```

The SIZE input must be set to size in bytes of the BUFR structure, use the SIZEOF function to get the size of the BUFR structure.

This function block will service incoming UDP requests but will not send unsolicited information to other controls.

When the EN00 input is energized, the function block creates a UDP socket on the protocol port defined in PORT on the Ethernet board designated in SLOT. PORT is chosen as any available protocol port greater than 1024. Both the client and the server must have the same PORT number.

The OK output is set if the function block was successful in opening and configuring the port.

The FAIL output is set if the function block was not successful in opening and configuring the port.

The ERR output specifies the type of error. Error codes are listed in Table 2-1 Ethernet ASFB Error Codes.

The ACTV output, when energized, indicates that the data at BUFR is currently in use by the function block and should not be read or written at this time.

**Table 2-1. Ethernet ASFB Error Codes**

<b>ERR#</b>	<b>Description</b>	<b>ERR#</b>	<b>Description</b>
-5	No response/timeout from client	37	Argument too large
-4	Loss of communications between PC and MMC for PC	38	Result too large
-3	Client received response from wrong Server	40	Destination address required
-2	Client/Server SIZE or READ inputs don't match	41	Protocol wrong type for socket
-1	No response/timeout from Steve	42	Protocol not available
0	No error	43	Protocol not supported
1	Not owner	44	Socket type not supported
2	No such file or directory	45	Operation not supported on socket
3	No such process	46	Protocol family not supported
4	Interrupted system call	47	Address family not supported
5	I/O error	48	Address already in use
6	No such device or address	49	Can't assign requested address
7	Arg list too long	50	Socket operation on non-socket
8	Exec format error	51	Network is unreachable
9	Bad file number	52	Network dropped connection on reset
10	No children	53	Software caused connection abort
11	No more processes	54	Connection reset by peer
12	Not enough core	55	No buffer space available
13	Permission denied	56	Socket is already connected
14	Bad address	57	Socket is not connected
15	Directory not empty	58	Can't send after socket shutdown
16	Mount device busy	59	Too many references: can't splice
17	File exists	60	Connection timed out
18	Cross-device link	61	Connection refused
19	No such device	62	Network is down
20	Not a directory	63	Text file busy
21	Is a directory	64	Too many levels of symbolic links
22	Invalid argument	65	No route to host
23	File table overflow	66	Block device required
24	Too many files open	67	Host is down
25	Not a typewriter	68	Operation now in progress
26	File name too long	69	Operation already in progress
27	File too large	70	Operation would block
28	No space left on device	71	Function not implemented
29	Illegal seek	72	Operation cancelled
30	Read-only file system	1000	There is a non-zero terminated string which requires zero termination or a zero length string.
31	Too many links	1001	There is a CNT input which is too large.

<b>32</b>	Broken pipe	<b>1002</b>	The SLOT number requested does not contain an Ethernet board.
<b>33</b>	Resource deadlock avoided	<b>1003</b>	Either the firmware does not support TCP/IP or there is no Ethernet board in the rack.
<b>34</b>	No locks available	<b>1004</b>	The IPZ buffer is too small.
<b>35</b>	Unsupported value	<b>1005</b>	A TCP/IP function was terminated due to a TCP/IP stack failure. The socket the function block is using is no longer valid. *
<b>36</b>	Message size		



# **Index**

## **A**

ASFB 1-1  
    Input/Output Descriptions 1-2  
    using 1-2

## **E**

E\_MAIL 2-3  
E\_TCPRD 2-5  
E\_TFTPCL 2-8

E\_TFTPSV 2-6  
E\_UDPCL1 2-10  
E\_UDPSV1 2-12  
Ethernet ASFBS 2-2

## **I**

Installation 1-1

## **R**

revision  
    history 1-1  
    range 1-2

## NOTES